
KT Header
20'-0"
10'-0"
10'-0"
Provide electrical power supply to box.
5'-0"
Mount box to KT header about 2'-0" from the end.
Conveyor # 1
Connect electrical power supply to box.
10'-0"
10'-0"
10'-0"
10'-0"
4'-0"
25'-0"
Run power supply from box to motor
Adjustable arm with electric sensor should be mounted to the KT header above the screw conveyor. This sensor will shut the motor o for 10 seconds and restart when conveyor #2 is empty.
Rotating clamp
10'-0"
Conveyor # 1
6'-0"
Sensor
Conveyor # 2